

Cleaning Eco-Grip® Floors

The biggest mistake that people cleaning floors can make is not thoroughly removing the used cleaning agent and contaminates

Daily Maintenance Instructions

1. Always place signs in highly visible areas warning people that the floors are wet and could be slippery.
2. Thoroughly sweep all debris from floor surface and remove to trash receptacle.
3. Pre-rinse the floor with **HOT** water. Use the hand-held sprayer when rinsing.
4. Attach foam gun directly to Eco-Grip® Daily Cleaner. Attach water hose to foam gun and turn nozzle to on position. Liberally apply foam to all floor areas. It is critical to use **HOT** water.
5. Using a deck brush quickly, but thoroughly scrub the kitchen floor area.
6. Allow Cleaner to dwell on floor for 8 minutes.
7. Scrub floor again in high grease areas.
8. Thoroughly rinse kitchen floor with **HOT** water.
9. Squeegee water down drain and allow floor to dry.



Manufacturing/International Distribution
1088 Gaffney Hwy • Jonesville, SC 29353
864-674-0018 ph • 864-674-0019 fax

National Training Center/SpeedFlex Production
8801 South Blvd • Charlotte, NC 28273
704-522-0597 ph • 704-522-0598 fax

sales@eco-gripfloor.com
customerservice@eco-gripfloor.com
www.eco-gripfloor.com



Made in USA